

Ultimate Upholstery Adhesive

Especially created for the upholstery trade. Upholstery adhesive produces a cob-web spray pattern which gives a low soak in on porous or absorbent surfaces such as foam or fabric.

Ideal for use on soft or pliable materials: maintains a durable bond even with hard surfaces

Exclusively formulated as a powerful, yet flexible bonding system perfect for soft or pliable materials such as foams, fabrics or felts and all other upholstery components, allowing them to be bonded to themselves, each other or to hard surfaces such as wood, chipboard, MDF, glass, rigid plastics and most other substrates. Upholstery Adhesive is now twinned with the new Easi-Flo valve and Easi-Control actuator system, which gives greater fingertip control; For larger areas, press actuator full on and move can away slightly. For narrower band widths or to apply less adhesive, press the actuator more gently and move can closer.

Designed as the ideal bonding solution for all upholstery materials

- Flexible and strong; when used correctly, the bond strength is such that the adhesive is stronger than the material being bonded.
- The only flammable component is the propellant. Once that has evaporated, a totally non-flammable bond is achieved.

Instructions for use:

1. Always ensure that the surfaces to be mated are clean, dry and free from any contaminants.
2. Apply a thin, even coat to both surfaces; Upholstery Adhesive, like all contact adhesives, is designed to stick to itself. Wet adhesive will stick to a surface but will not bond two surfaces together properly.
3. Allow 1-2 minutes for the adhesive to tack-up, when there is no adhesive transference to the finger, bring both surfaces together starting with the centre and working outwards.

Whilst handling the adhesive, we advise to avoid spillage, to keep away from heat, sparks and open flames and to use the adhesive in well ventilated areas. For best results the adhesive should be used at temperatures between 15°C - 25°C and stored in temperatures between 10°C - 20°C, in dry, well ventilated areas and must not be exposed to direct sunlight or temperatures above 50°C.

Application:

When bonding foam, spray lightly onto the surface to avoid saturating the foam. Saturated foam usually leads to solvent entrapment, which will not allow bond strength to develop. It is important to spray both surfaces. Do not spray a heavy coating on one surface only and expect the product to bond properly.

Upholstery Adhesive works best between 15°C and 25°C in low humidity; extremes of temperature or high humidity will slow the drying time. Never bring the surfaces together prematurely as solvents will be trapped, causing air bubbles over time. Excess adhesive may be removed with solvent cleaner. This adhesive is not suitable for heavily plasticised PVC.

An evaluation of the adhesive should be carried out in application conditions before commercial use is undertaken, this should also include reference to ageing. This product can be stored for 12 months from date of purchase.

IMPORTANT NOTES:

Temperature and timings: All information on temperature and timings represent normal working conditions and is provided as a guideline only. However, please contact Adkwik for advice if you wish to operate outside of these parameters.

Storage and handling: The product should be stored unopened in a dry condition at a temperature of 5-25°C. This will ensure the stated shelf-life. The adhesive will have a limited life once the container is opened.

Disclaimer: Adkwik has taken care to ensure that the information provided in the literature is correct and up to date. However, it is not intended to form any part of a contract or provide a guarantee. Purchasers/intending purchasers should contact Adkwik to check whether there have been any changes to the information since publication of the literature. Please ensure you have read the hazard labels and material safety data sheet before using this product.